

- FOR PREPARATION OF TRIM, REFER TO SEPARATE TEMPLATE.
- DIMENSIONS GIVEN IN INCHES AND (MM).

## RESPONSIBILITY Door and Frame Manufacturers are responsible for providing adequate construction or reinforcements for proper installation of hardware shown.

NOTES:

CROSSBAR RIM BY VERTICAL ROD DEVICES

ED6200 BY ED6400 SERIES

BY SO2 STRIKE



TEMPLATE CROSS REFERENCE

DO NOT SCALE DRAWING

SUPERSEDES WT30105 03/29/93

BTH

All architectural builders hardware must be installed on properly reinforced doors and frames, regardless of the type, material, or method of construction.