

Sex nuts or through bolts ***are required*** for wood and plastic covered composite doors, and any type of door without reinforcements and ***recommended*** for wood core and metal clad (Kalamein) type doors.

T30522

T 3 0 5 3 6