



Notes:

1. This template is an addition to the device template. Locate centerlines using horizontal and vertical references on device template.
2. Do not scale drawing.
3. Dimensions are in inches (mm).
4. LHR door shown. Preparation is typical for both door hands.
5. Prepare mounting holes when installing trim.
6. For door reinforcement see template 7400-0000.
7. Provide adequate internal support to prevent door deformation after trim is bolted to the door.

**214F Trim Application for Metal Doors
with 2100(F) Series Rim and Vertical Rod Exit Devices**

Yale®	
Yale Commercial Locks and Hardware	
www.yalecommercial.com	
TEMPLATE NUMBER	DATE
7400-0214	8-99